



Procedure for initial flash placement:

- 1) At the camera position, measure the width of the A-frame to the right and left of the camera.
- 2) Strike a line from this point to the corner of the A-frame.

This determines the "Angle of Incidence". (dashed blue lines)

The flashes will need to be at least 3' outside of this line on both sides.

- 3) Strike a 17' Arc from each corner of the A-frame. (dashed blue arcs)
- 4) Measure 36" perpendicular from the angle of incidence to the arc.
- 5) Place the Flash on this point to start.

Do not bolt down the flash, the final placement will be determined during the initial calibration.